

Comfort-Mesh Drafting

Models

91-02406115/91-02409115

Parts

IMPORTANT NOTICE

YOU WILL FEEL A SLIGHT
"BOUNCE-BACK" WHEN YOU SIT DOWN.
THIS IS NORMAL: NOT A DEFECT.
THE PNEUMATIC CYLINDER FOR THE
SEAT HEIGHT ADJUSTMENT REACTS TO
YOUR WEIGHT BY GIVING A LITTLE




A. [1] Base Plate Mechanism

B. [2] Armrests

C. [1] Backrest

D. [1] Seat




E. [1] 5-Star Base

F. [1] Foot Ring with Knob
Model 91-02406115 only.

G. [1] Plastic Ring insert
Model 91-02406115 only
(This part can be found in
the foot ring Part F)

H. [1] Black Cylinder
Bellows
Model 91-02409115 only

I. [1] Cylinder
[I-1] 91-02406115 model
[I-2] 91-02409115 model



J. [10] M6X35mm Hex Head Bolts



K. [4] M6X20mm Hex Head Bolts




L. [5] Castors

IMPORTANT

If you have difficulty assembling your chair or need customer service assistance. Please call: Martin Universal Design, Inc. Customer Service Hot Line at 1-313-895-0700. If you need additional parts, it is not necessary to contact your dealer, our Customer Service Rep. will forward them to you immediately.


MARTIN
Universal Design, Inc.

4444 Lawton St, Detroit MI 48208 USA
Tel:(313)895-0700 • Fax:(313)895-0709
E-mail: Custservmud@gmail.com
Visit us at:
www.MartinUniversalDesign.com



Place 5-star base (E) face down and push [5] castors (L) into each position.

2. knob on foot ring




Cut ends of plastic insert must run parallel with the weld.

THIS STEP IS ONLY FOR MODEL 91-02406115 ONLY.

Before attaching foot ring (F) to cylinder (I). Begin by loosening the knob on the foot ring and position the plastic ring insert properly, by making sure the cut ends of the insert run parallel with the weld on the inside of the foot ring hole. The insert should be already in the foot ring. **NOTE: THIS MUST BE POSITIONED PROPERLY TO ALLOW THE CYLINDER TO SLIDE THROUGH THE INSERT EASILY.**

3.



Slide cylinder down through foot ring and tighten knob. After chair is assembled completely, you may adjust foot ring to desired height. *This step is only for Model 91-02406115.

4.



Model # 91-02409115




PLEASE NOTE: If you have model number 91-02406115 your assembly will be the same but instead of foot ring you will need to place black bellows (H) over top of cylinder after inserting cylinder into base. Insert wider end of cylinder into hole in base, as shown above.

5.



Attach mechanism (A) to seat (D) using [4] M6X20mm hex head bolts (K). See picture above for specified locations that are circled. Tighten with hex wrench. Attach as shown in the order pictured below::



6.



Attach back rest (C) to seat mechanism using [4] M6X35mm bolt (J). Please see circled areas in the above picture for locations of screw holes.

Attach armrests (B) to bottom side of seat using [3] M6X35mm bolts (J) per armrest (B). Please see Circled areas in the above picture for locations of bolt holes. Tighten with hex wrench.



Please note the direction and placement of armrest (B) in the above picture.

Finished Product



Assembled
91-02409115

Assembled
91-02406115