



IMPORTANT NOTICE

YOU WILL FEEL A SLIGHT
 "BOUNCE-BACK" WHEN YOU SIT DOWN.
 THIS IS NORMAL: NOT A DEFECT.
 THE PNEUMATIC CYLINDER FOR THE
 SEAT HEIGHT ADJUSTMENT REACTS
 TO YOUR WEIGHT BY GIVING A LITTLE


PARTS



A. [1] Base Plate Mechanism



B. [1] Cylinder
 [a] 91-02606 model [b] 91-02609 model
 C. [5] Castors




D. [1] Plastic Ring insert
 Model 92-02609 only
 (This part can be found in
 the foot ring Part F)



E. [1] 5-Star Base



F. [1] Foot ring with knob
 Model 92-02606 only




G. [1] Backrest




H. [1] Seat



I. [1] Black Cylinder Bellows
 Model 92-02609 only



J. [4] M6X20 Hex Head Screws



K. [6] M6X25 Hex Head Screws



M. [2] Armrests

GRANDEUR Model's 91-02606115 & 91-02609115




IMPORTANT
 If you have difficulty assembling your chair or need customer service assistance.
 Please call: Martin Universal Design, Inc. Customer Service Hot Line at
 1-313-895-0700. If you need additional parts, it is not necessary to contact your
 dealer, our Customer Service Rep. will forward them to you immediately.


MARTIN
 Universal Design, Inc.

4444 Lawton Avenue, Detroit MI 48208 USA
 Tel:(313)895-0700 • Fax:(313)895-0709
 E-mail: Custservmud@aol.com
 Visit us at: www.MartinUniversalDesign.com

Revised 11/2013 MUD




1. Place 5-star base (E) face down and push [5] castors (C) into each position.




2. Cut ends of plastic insert must run parallel with the weld.


THIS STEP IS ONLY FOR MODEL 92-02606 ONLY. Before attaching foot ring (F) to cylinder (B). Begin by loosening the knob on the foot ring and make sure the plastic rings is inserted properly, by making sure the cut ends of the insert run parallel with the weld on the inside of the foot ring hole. The insert should be already in the foot ring. NOTE: THIS MUST BE POSITIONED PROPERLY TO ALLOW THE CYLINDER TO SLIDE THROUGH THE INSERT EASILY.




3. Slide cylinder down through foot ring and tighten knob. After chair is assembled completely, you may adjust foot ring to desired height.




4. PLEASE NOTE: If you have model number 92-02609, your assembly will be the same but instead of foot ring you will need to place black bellows over top of cylinder after inserting cylinder into base. Insert wider end of cylinder into hole in base, as shown above.




5. Attach mechanism (A) to seat (H) using [4] M6x20 screws (J). See picture above for specified locations that are circled. Tighten with hex wrench.



6. Attach backrest (G) to seat mechanism (A), by inserting backrest support bar into oval hole in mechanism. Tighten knob on mechanism to secure.



7. Attach armrests to bottom side of seat. Each Armrest (M) uses [3] screws (M6x25) on each arm.



8. Attach seat/backrest/armrest assembly to cylinder by inserting top of cylinder into hole on bottom of seat mechanism. Weight of sitting on seat will secure seat assembly to cylinder.

NOTE: 2 Paddles below seat are for seat height adjustment & Backrest tilt adjust ments.
NOTE2: PERIODIC RE-TIGHTENING of Armrests screws may be needed throughout use of chair over the years.